



**Edwards Vacuum E2M18 Maintenance Kit, 36301800 – Parts List**

<b>DESCRIPTION</b>	<b>PART NO.</b>	<b>QTY</b>
Spring	E00307046	2
Drain Plug	E00714012	2
Vane Spring	E00906077	3
Filter Seal	E01403030	2
Dowty Seal	E02104001	2
Dowty Seal	E02104012	1
Viton Shaft Seal	E02109064	1
Viton Shaft Seal	E02109067	1
O-Ring	E02120028	8
O-Ring	E02120033	1
O-Ring	E02120035	1
O-Ring	E02120037	1
O-Ring	E02120057	1
O-Ring	E02120067	1
O-Ring	E02120072	1
O-Ring	E02120078	2
O-Ring	E02120089	2
O-Ring	E02122108	1
O-Ring	E02125026	2
O-Ring	E02126116	2
Gas Ballast Filter	E02308043	2
Gas Ballast Gauze	E02308044	2
Ballast Valve	E11301045	1
Oil Pump Vane	E20402120G	1
2 <sup>nd</sup> Stage Vane	E20402121G	2
1 <sup>st</sup> Stage Vane	E20402123G	2
Waved Washer	E218990201	1
Felt Pad	E22302017	1
Oil Filter Assy	E22305008	1
O-Ring	E23724072	1



## Edwards Vacuum E2M18 Maintenance Kit, 36301800 – Parts List

Valve Pad	E26501029	3
Coupling Element	E26501032	1
Valve Spring	E27102030	2
Distributor Spring	E27102032	1
Valve Spring	E27102033	2
Distributor Rubber	E27159430	1
S/G Gasket – Rubber	E27159530	1
Oil Case Gasket	E27159635	1
S/G Gasket – Paper	E27159638	1
Spring Pin	E29203002	2
Spring Pin	E29203003	3

### **A & J Vacuum Services, Inc.**

790 Bloomfield Ave, Suite B3

Clifton NJ 07012 USA

973-249-0854